

Panasonic adapter cable for electronic hook switch |
 Panasonic Adapterkabel für elektronische Fernabnehmer |
 Câble adaptateur Panasonic pour décrocheur à distance électronique | Panasonic adapterkabel til elektronisk tørløft

DW series

4

SD series

4

D 1.0 series

4

standard
Siemens II
Panasonic
standard
standard
standard
standard

standard
Siemens II
Panasonic
standard
standard
standard
standard

standard
Siemens II
Panasonic
standard
standard
standard
standard

DW series

1

SD series

1

D 1.0 series

1

▶ Connect the base station to the mains.

DW series

2

SD series

2

D 1.0 series

2

DW series

3

SD series

3

D 1.0 series

3

▶ Push all DIP switches down.

DW series

5

SD series

5

D 1.0 series

5

... LED off

... LED off

... LED off

▶ Push DIP switches 2 to 6 up.

DW series | SD series | D 1.0 series

6

next steps: see back page